

minipack®-america
Packing Machines and Systems
1-877-minipack



Technical Update

Changing the seal blade voltage.

Step 1
Remove the rear panel to
expose the T1 transformer.



Step 2.
Move the input voltage wire
To the 200 volt tap.

